

# Product Data

# Somos<sup>®</sup> NeXt

## Description

Somos<sup>®</sup> NeXt is an extremely durable stereolithography (SL) resin that produces very accurate parts with high feature detail. Based on the Somos<sup>®</sup> DMX technology, Somos<sup>®</sup> NeXt is a next generation of material that facilitates the production of tough, complex parts with improved moisture resistance and greater thermal properties.

## Applications

Somos<sup>®</sup> NeXt produces parts that are much more resistant to breakage than parts made with standard SL resins. It is ideal for use in functional testing applications as well as low-volume manufacturing applications where toughness is required. Market segments include aerospace, automotive, medical, consumer products and electronics.

This resin is ideal for functional end-use performance prototypes such as: snap-fit designs, impellers, duct work, connectors and electronic covers, automotive housings and dashboard assemblies, packaging and sporting goods.

### TECHNICAL DATA - LIQUID PROPERTIES

Appearance	White
Viscosity	~1,000 cps @ 30°C
Density	~1.17 g/cm <sup>3</sup> @ 25°C

### TECHNICAL DATA - OPTICAL PROPERTIES

E <sub>c</sub>	12.0 mJ/cm <sup>2</sup>	[critical exposure]
D <sub>p</sub>	5.80 mils	[slope of cure-depth vs. ln (E) curve]
E <sub>10</sub>	67.0 mJ/cm <sup>2</sup>	[exposure that gives 0.254 mm (.010 inch) thickness]

TECHNICAL DATA			
Mechanical Properties		Somos® NeXt Postcure	
ASTM Method	Property Description	Metric	Imperial
D638M	Tensile Modulus	2,370 - 2,490 MPa	343 - 361 ksi
D638M	Tensile Strength at Yield	41.1 - 43.3 MPa	5.9 - 6.3 ksi
D638M	Tensile Strength at Break	31.0 - 34.6 MPa	4.5 - 5.0 ksi
D638M	Elongation at Break	8 - 10%	8 - 10%
D638M	Elongation at Yield	3%	3%
D638M	Poisson's Ratio	0.42 - 0.44	0.42 - 0.44
D790M	Flexural Strength	67.8 - 70.8 MPa	9.8 - 10.3 ksi
D2240	Flexural Modulus	2,415 - 2,525 MPa	350 - 366 ksi
D256A	Izod Impact (Notched)	0.47 - 0.52 J/cm	0.88 - 0.97 ft-lb/in
D2240	Hardness (Shore D)	82	82
D570-98	Water Absorption	0.39 - 0.41%	0.39 - 0.41%

TECHNICAL DATA			
Thermal/Electrical Properties		Somos® NeXt Postcure	
ASTM Method	Property Description	Metric	Imperial
E831-05	C.T.E. -40 - 0°C (-40 - 32°F)	71.5 - 74.3 $\mu\text{m}/\text{m}^\circ\text{C}$	39.7 - 41.3 $\mu\text{in}/\text{in}^\circ\text{F}$
E831-05	C.T.E. 0 - 50°C (32 - 122°F)	106.5 - 114.5 $\mu\text{m}/\text{m}^\circ\text{C}$	59.2 - 63.6 $\mu\text{in}/\text{in}^\circ\text{F}$
E831-05	C.T.E. 50 - 100°C (122 - 212°F)	168.6 - 175.4 $\mu\text{m}/\text{m}^\circ\text{C}$	93.7 - 97.4 $\mu\text{in}/\text{in}^\circ\text{F}$
E831-05	C.T.E. 100 - 150°C (212 - 302°F)	168.8 - 176.4 $\mu\text{m}/\text{m}^\circ\text{C}$	93.8 - 98.0 $\mu\text{in}/\text{in}^\circ\text{F}$
D150-98	Dielectric Constant 60 Hz	4.65	4.65
D150-98	Dielectric Constant 1 KHz	3.97	3.97
D150-98	Dielectric Constant 1 MHz	3.62	3.62
D149-97a	Dielectric Strength	14.9 - 15.5 kV/mm	379 - 395 V/mil
E1545-00	Tg	43 - 47°C	109 - 116°F
D648	HDT @ 0.46 MPa (66 psi)	55 - 57°C	131 - 134°F
D648	HDT @ 1.81 MPa (264 psi)	48 - 51°C	118 - 124°F

## DSM Functional Materials Somos® Materials Group

### in North America

1122 St. Charles Street  
Elgin, Illinois 60120  
USA  
Phone: +1.847.697.0400

### in Europe

Slachthuisweg 30  
3150 XN Hoek van Holland  
The Netherlands  
Phone: +31.174.315.391

### in China

476 Li Bing Road  
Zhangjiang Hi-Tech Park  
Pudong New Area  
Shanghai 201203, China  
Phone: +86.21.6141.8064

Visit us online at [www.dmsomos.com](http://www.dsmsomos.com)

NOTICE : Somos® is a registered trademark of Royal DSM N.V. Somos® is an unincorporated subsidiary of DSM Desotech Inc. The information presented herein is based on generally accepted analytical and testing practices and is believed to be accurate. However, DSM Desotech expressly disclaims any product warranties which may be implied including warranties or merchantability and/or fitness for a particular purpose DSM Desotech's products are sold subject to DSM Desotech's standard terms and conditions of sale, copies of which are available upon request. Purchasers are responsible for determining the suitability of the product for its intended use and the appropriate manner of utilizing the product in purchaser's production processes and applications so as to insure safety, quality and effectiveness. Purchasers are further responsible for obtaining necessary patent rights to practice any invention in connection with the use of purchased product and any other product or process. DSM Desotech reserves the right to change specifications of their products without notice. © 2012 DSM IP ASSESTS B.V. All rights reserved.